

# HAMSTEAD SOUNDWORKS

## AMP SWITCHER INTERFACE



• TRS output to the Footswitch Input on the rear panel of the Hamstead Artist Series Amplifier.

• TRS input to control the Reverb and Tremolo from a switching system output\*.

• TRS input to control the FX Loop and Voice from a switching system output\*.

\*Switching outputs include: “*Remote Switch*” (GigRig), “*EXT CTL*” (Boss) or “*Func Sw*” (RJM).